

## RBT18543 TOOL KIT INCLUDES

### TOP SHELF

LOC	QTY.	TOOL No.	DESCRIPTION
A	1	RBT18538	SEAT FRAME SUPPORTS
B	1	RB2300COMB	POWER TURBINE CLEANING KIT
C	1	RBPA003	T/R DRIVE SHAFT BRG. LUBE TOOL
D	1	RBE-RDGS-15	SCALE TESTER
E	1	RBT18543-9	M/R PILLOW BLOCK NUT WRENCH
F	1	RB6798292-B	FUEL CONTROL WRENCH
G	1	RBT18546	K-FLEX WRENCH
H	1	RBT18565	ENGINE BELL MOUTH RATCHET
I	1	RB23007638	FUEL NOZZLE WRENCH
J	1	RBT18524	OIL SUMP STRAIGHTENER
K	1	RBT400203	M/R TRIM TAB PROTRACTOR
L	1	RBT400202	M/R TRIM TAB BENDER
M	1	RBT18543-11	CROWSFOOT INB. HYD. FILTER
N	1	RBT200078	TRUNNION SPREADER
O	1	RB23006782	ADAPTER TURBINE NUT, LOWER
P	1	RB23006783	ADAPTER TURBINE NUT, UPPER
Q	1	RBT18551	SWASH PLATE SHIM BOLTS
R	1	RBT18505	T/R CROSS HEAD PULLER

### BOTTOM SHELF

LOC	QTY.	TOOL No.	DESCRIPTION
S	2	RBT18543-15	M/R SLING ASSY
T	1	RBGTMD12	M/R PILLOW BLOCK BOLT SOCKET
U	1	RB6796941-14	STARTER SEAL GUIDE
V	1	RBIR7028	BEARING INSTALL & REMOVE
W	1	RBSC7028-P	S/P PITCH HORN BRG. CUTTER
X	1	RBST2812-P	S/P PITCH HORN BRG. SWAGING TOOL
Y	1	RB DB3188L-13	TRANSMISSION DRAIN TOOL QUILL ASSY
Z	1	RB DB3225L-13	T/R G/B & FW UNT DRAIN TOOL QUILL ASSY
AA	1	RB DB3225C-17	FREE WHEELING CLUTCH TOOL QUILL ASSY
AB	2	RBT18506	M/R MAST NUT SOCKET
AC	1	RBT18540	HELICOPTER LIFTING EYE
AD	1	RB6796941-201	STARTER PULLER ASSY.
AE	1	RB6796941-203	SLIDE HAMMER ASSY.
AF	1	RB6796941-18	STARTER SEAL INSTALLER
AG	1	RBT18543-17	BLADE BOLT LATCH SOCKET
AH	2	RBT18666	M/R RESTRAINT TOOL
AI	1	RBBP1425-101	INPUT DRIVE SHAFT TOOL KIT
AJ	1	RBT112800	PTO SEAL INSTALL TOOL
AK	1	RBT18560	SEAL PULLER ENGINE GEARBOX
AL	1	RB H4713-17	T/R & G/B DRAIN TOOL QUILL ASSY
AM	1	RB DB3118L-15	T/R DRAIN TOOL HOSE ASSY
AN	1	RB DB3225C-19	FW CLUTCH DRAIN TOOL HOSE ASSY
AO	1	RB DB3225L-15	T/R G/B & FW HOSE ASSY
AP	1	RB H4713-19	T/R & G/B DRAIN TOOL HOSE ASSY



1270 ABERDEEN STREET  
HAWKESBURY, ON, K6A 1K7  
CANADA

TEL: 1 613 632 5200

e-mail: support.ON@dartaero.com